

Installation, Operation & Maintenance Manual

EFI TankLite™



116 Main Street. PO BOX 925, Farmingdale, NJ 07727-0925
Tel 732-938-5641 www.ernstflow.com Fax 732-938-9463

STORAGE and HANDLING

The EFI TankLite™ meets or exceeds all applicable specifications when shipped from the factory.

All units should be inspected upon receipt to ensure that no damage has been incurred during transit. If there has been damage, a claim should be filed with the carrier immediately. Unit should be stored in an area protected from the elements and corrosive fumes, in a secure manner where they can neither fall, nor be struck by other objects. Care should be taken to protect the window and the end connections from damage. Avoid placing any objects directly on the light at any time.

COMPONENTS

There are three main components that make up the LED illuminator: the LED housing, power supply, and cable connecting these two main pieces. The cable may have more than one piece depending on the required distance between the illuminator and power supply. Questions regarding acceptable applications should be directed to Ernst Flow Industries™.

ELECTRICAL CONNECTION

CAUTION: All lights are tagged with the service conditions for that particular unit. These specifications are located on the Ernst Flow Industries™ tag on the power supply housing, and are contained in the “Specifications” section of this manual. Review the ratings prior to installation and again prior to start-up.

Note: All installation steps should be performed by a qualified technician and should be executed in accordance with all applicable national and local codes.

The light and power supply should be checked to ensure that they contain no foreign matter, and that the end connections are clean and undamaged.

CAUTION: Before working with power supply, verify that the area is free of flammables and AC power circuit is off.

- 1) Mount LED housing to the sight flow or sight window with supplied mounting hardware.
- 2) Open the cover of the power supply housing. Insert the AC Line wires into the housing and connect to the “AC IN” terminal block. Ground screws are located inside and outside the enclosure. **CAUTION:** The DC output is pre-wired. If this connection is removed during installation, reconnect the “AC IN” and “DC OUT” to the proper positions. Failure to do so will result in permanent damage to the power supply. (Ref. Fig. 1, pg. 4)

IMPORTANT: A sealing fitting must be installed within 18” of the enclosure when mounting in Hazardous Locations.

- 3) If the cable will not reach the power supply, contact Ernst Flow Industries™ for the required extension cable.
- 4) Replace the cover on the power supply housing.
- 5) Switch “ON” the power supply making sure the Illuminator is functioning properly, with all LED’s illuminated.
Warning: To avoid damage to eyes, do not look directly into the TankLite.
- 6) Refer to the troubleshooting section in this manual if a portion or all of the LEDs do not illuminate.

ROUTINE MAINTENANCE

Keep window on the front of the light clean using commercial glass cleaners, such as Windex® or similar. Never use harsh abrasives, wire brushes, metal scrapers, or any material that could scratch the window. The window may be cleaned while the unit is in operation.

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™

SPECIFICATIONS

Power Supply:	120 or 240 VAC @ 50-60 Hz
Power Consumption:	< 1A @ 120 VAC < 0.5A @ 240 VAC
Est. Life:	100,000 Hours (continuous)
Approvals:	FM Class I, Div. 1 Groups B, C, D T4 CSA Class I, Div. 1 Groups B, C, D T4 Associated Equipment [Exia]
Ambient Temp:	-40 F (-40 C) to 170 F (77 C)
Wire Size:	Min 18 AWG / Max 12 AWG
Cable Inductance:	0.12uH/ft (0.036uH/m)
Max dist. power supply to light:	72 feet (22M)
Electrical Connection:	¾" FNPT

EFI TankLite™ Spare Parts	
Description	P/N
4" LED Assembly Anodized Aluminum	TIK-PH4-RING-L
6" LED Assembly Anodized Aluminum	TIK-PH6-RING-L
4" LED Assembly 316SS	TIK-PH4-RING-S
6" LED Assembly 316SS	TIK-PH4-RING-S
Bracket Kit for .500" - .875" Thick Retainers	TPH-BRKT-1
Bracket Kit for .875"- 1.25" Thick Retainers	TPH-BRKT-2
120 VAC FM / CSA Power Supply w/ Epoxy Coated Aluminum Explosion-Proof Enclosure	TPS-4856-120
240 VAC FM / CSA Power Supply w/ Epoxy Coated Aluminum Explosion-Proof Enclosure	TPS-4856-240
Fuse (400 mA, Ceramic Cartridge, ATEX Certified)	E-F-DIN-F400MA (4 Fuses)
Fuse (400 mA Fast Acting)	E-F-DIN-F400SP (4 Fuses)
6-1/2 foot Extension Cable (for Remote Mounting)	V20601-6.5
16 foot Extension Cable (for Remote Mounting)	V20601-16
32 foot Extension Cable (for Remote Mounting)	V20601-32
Standard Mounting Kit	X175585
M20 metric brass adaptor (3/4"MNPT x M20 female)	V19705-F

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™

Troubleshooting

Description of Problem	Possible Cause	Troubleshooting Procedure
All LEDs out	No AC line voltage Blown Fuse Loose or disconnected DC output wires Blue Power Cord loose or connector damaged Loose or damaged connections inside LED Assembly Damaged Power Supply Defective LED board or loose connections inside LED housing	Follow troubleshooting steps below
(2) LEDs out	Defective LED Board or loose connection inside LED housing	Contact Ernst Flow Industries™

Troubleshooting Steps

Caution: Some of these troubleshooting steps are performed with live voltage applied. The assembly should be moved to a safe area before beginning work. A qualified and properly trained technician must perform these steps.

NOTE: See Figure 1 on next page for component locations.

- 1) Remove enclosure cover and look to see if red LED power indicator is on.
 - a) If red LED is on, go to step 4.
- 2) Check AC wiring to make sure it is properly installed and tightened in connector.
- 3) Using a meter, verify AC line voltage at AC connector.
- 4) Disconnect AC power. Using a small pair of needle-nose pliers, gently remove fuse from holder.
- 5) Check fuse for continuity with an Ohm meter. If there is continuity, re-install fuse. If there is no continuity, replace fuse.
- 6) Check DC output wiring to make sure it is properly installed and tightened.
- 7) Reconnect AC power.
- 8) Using a voltmeter set to DC; measure the voltage across the output connector. Voltage should be between 9VDC and 15VDC.
- 9) Unscrew and remove blue power cord. Inspect the 4 pins inside end connector to make sure they are straight and undamaged. If pins are bent, use a small pair of needle-nose pliers to straighten bent pins. If pins are missing, contact factory.
- 10) Reconnect power cord making sure connectors are fully seated and tightened.
- 11) If all steps above check OK, contact Ernst Flow Industries™ for support.

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™




Figure 1

REPLACEMENT OF POWER SUPPLY SUB ASSEMBLY (ALL MODELS)

NOTE: Make sure AC power is off before removing cover.

- 1) Loosen cover locking screw and open the cover of the power supply housing. Disconnect AC power and remove AC wires from enclosure.
- 2) Remove assembly from gauge and relocate to desired work area.
- 3) Unplug DC power plug.
- 4) Remove 2 screws holding power supply sub assembly in place.

NOTE: Screws are installed with liquid thread lock. If screws will not come loose, sharply hit the back of the screwdriver with a hammer to help release the hold of the thread lock.

- 5) Place new power supply into position in the enclosure, apply permanent liquid thread lock to the screws and reinstall screws.
- 6) Re-connect DC power plug and bench test unit by applying AC through the AC Input Connector (ref. Figure 1).

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™

NOTES:

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™



**VISIT OUR ONLINE STORE:
[SHOP.ERNSTFLOW.COM.](http://SHOP.ERNSTFLOW.COM)**

ERNST FLOW INDUSTRIES
A CLARK-RELIANCE COMPANY™