



Mini-Mag Float Installation Procedure

Use the following steps to install the float inside of the chamber. All other setup and maintenance procedures should be done in accordance with the Magnicator Installation, Operation, & Maintenance, IOM document M500.01, manual that comes with the gage.

- Find the arrow on the tag that is etched onto the float. The arrow tip locates the proper pole of the magnet inside of the float.
- Insert float into the chamber with the arrow tip, and magnet, facing towards the indicator.

Completing these steps will ensure proper coupling between the magnets in the float and the indicator during startup and operation.

